




Originale	Sostituto
 Power	 Power
 3D	 3D
 Tv Input	 TV/R
 AV Input	 AV
 Menu	 Menu
 [=]/Text	 Text
 [=♦]/STTL	 Subt
 [+]/Aspect	 D. Menu
 X/Exit	 Exit
 i	 Info
 APPS	 Format
 Home	 Smart
 Guide	 Guide
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left

Originale	Sostituto
 OK	 Ok
 Option	 Options
 Return/Back	 Back
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 PR+	 Ch +
 PR-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5





Originale		Sostituto		Originale	Sostituto
6 _{mno}	6	6	6		
7 _{pqrs}	7	7	7		
8 _{tuv}	8	8	8		
9 _{wxyz}	9	9	9		
0	0	0	0		
? _{eHELP}	?/Help	SOUND DUAL	Dual		
↺ _{LAST VIEW}	Last View	FAV PRE-CH	Pre Ch		
⏪	<<	⏪	<<		
▶	Play	▶ _{PLAY MODE}	Play		
⏩	>>	⏩	>>		
⏮	I<<	⏮	I<<		
⏸	Pause	⏸	Pause		
⏭	>>I	⏭	>>I		
■	Stop	■	Stop		
●	Rec	● _{REC MODE}	Rec		

