




















































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Exit		Exit
	Mute		Mute		PR+		Ch +
	1		1		PR-		Ch -
	2		2		Vol+		Vol +
	3		3		Vol-		Vol -
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK/List		Ok
	9		9		↑		>>
	0		0		↓		<<
	Tv/Radio		TV/R		Pause		Pause
	←PR		Back		Red		Red
	EPG		Guide		Green		Green
	Menu		Menu		Yellow		Yellow
	Info		Info		Blue		Blue





Originale		Sostituto		Originale		Sostituto	
	Power		Power		Exit		Exit
	Mute		Mute		Up/PR+		Up
	1		1		Down/PR-		Down
	2		2		OK/List		Ok
	3		3		Right		Right
	4		4		Left		Left
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		↑		Ch +
	8		8		↓		Ch -
	9		9		Pause		Pause
	0		0		[+]		3D
	Tv/Radio		TV/R		FAV		Pre Ch
	←PR		Back		UHF		Smart
	EPG		Guide		PAL/NTSC		Format
	Menu		Menu		TV/AV		AV
	Info		Info		Red		Red



