



































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Red		Red
	Menu		Menu		Green		Green
	3D		3D		Yellow		Yellow
	TV Input		TV/R		Blue		Blue
	AV Input		AV		Mute		Mute
	i		Info		Text		Text
	Exit		Exit		STTL		Subt
	Internet		Media		[+]/Aspect		Format
	Viera Tools		Smart		Vol+		Vol +
	Guide		Guide		Vol-		Vol -
	Option		Options		CH+		Ch +
	Back/Return		Back		CH-		Ch -
	Up		Up		1		1
	Down		Down		2		2
	Right		Right		3		3
	Left		Left		4		4
	OK		Ok		5		5





	Originale	Sostituto	Originale	Sostituto
	6			
	7			
	8			
	9			
	0			
	Surround			
	Last View			
	<<			
	Play			
	>>			
	I<<			
	Pause			
	>>I			
	Stop			
	Rec			

