







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Left		Left
	Open/Close		Eject		Angle		Format
	<<		<<		Subtitle		Subt
	>>		>>		Audio		Dual
	l<<		l<<		Setup		Options
	>>l		>>l		Display		Info
	Pause/Step		Pause		Zoom		Shift + Eject
	Stop		Stop		Slow		AV
	Play		Play		E.A.M		Text
	Top Menu		Shift + Menu		E.P.M.		Media
	Menu		Menu		FL Select		List
	Clear		Exit		FL Dim		3D
	Back		Back		1		1
	Ok		Ok		2		2
	Up		Up		3		3
	Down		Down		4		4
	Right		Right		5		5





	Originale	Sostituto	Originale	Sostituto
	6	6		
	7	7		
	8	8		
	9	9		
	0	0		
	+10	Guide		
	T Search	TV/R		
	Random	Red		
	Memory	Green		
	Repeat	Shift + Text		
	A-B Rpt	Blue		

