







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Vol+		Vol +
	DTV/VCR		AV		Vol-		Vol -
	Info		Info		Recall		Back
	Play		Play		Game		Smart
	Pause		Pause		Rec List		List
	Mute		Mute		1		1
	Exit		Exit		2		2
	Menu		Menu		3		3
	EPG		Guide		4		4
	Favorite		Pre Ch		5		5
	Up		Up		6		6
	Down		Down		7		7
	Right		Right		8		8
	Left		Left		9		9
	OK		Ok		0		0
	CH+		Ch +		Tv/Radio		TV/R
	CH-		Ch -		Audio		Dual





Originale		Sostituto		Originale		Sostituto	
	Subtitle		Subt				
	Text		Text				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Record		Rec				
	Stop		Stop				
	>>		>>				
	<<		<<				

