





































Originale	Sostituto
 Source	 AV / Input / RDS
 Power	 Power
 Sound	 Sound / Title
 *	 Set up / OPT /
 [ + ]	 Picture / Format
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 [ OO ]	 Gui de / EPG / - / -
 Up	 Up
 [ i + ] / [ ? ]	 I n f o / Angl e
 Left	 Left
 OK	 OK
 Right	 Right
 Ret ur n	 Shi ft + Back / Ret ur n
 Down	 Down

Originale	Sostituto
 [ > < ] / PC	 Fav / Marker / PC
 Menu	 Menu / Home
 Anal og	 Di spl ay / Medi a
 Di gi tal	 Smart / Li st
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Text	 Text / Got o
 0	 0
 Recal l	 Back / Ret ur n
 Vol +	 Vol +



