




































































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Tv/Radio	 TV/R
 ←PR	 Back
 EPG	 Guide
 Menu	 Menu
 Info	 Info

Originale	Sostituto
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK/List	 Ok
 PR+	 Ch +
 PR-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 ↑	 Smart
 ↓	 Media
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Lang	 Dual





Originale		Sostituto		Originale	Sostituto
	TXT		Text		
	[...]		Subt		
	Audio L/R		Options		
	[+]		3D		
	FAV		Pre Ch		
	UHF		D. Menu		
	Tv/AV		AV		
	PAL/NTSC		Format		
	Record		Rec		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	<<		<<		
	>>		>>		
	< Seek		I<<		
	Seek >		>>I		

