


































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Vol-		Vol -
	Home		Smart		123/Input		AV
	Back		Back		3D		3D
	Micro		Dual		Mute/AD		Mute
	Tv		TV/R		P+		Ch +
	Mouse Down		>>		P-		Ch -
	Mouse Up		<<				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	OK		Ok				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Vol+		Vol +				


































































Originale	Sostituto
 Power	 Power
 Wheel Down	 Shift + Down
 OK	 Ok
 Up	 Up
 Down	 Down
 Wheel Up	 Shift + Up
 Right	 Right
 Left	 Left
 Back	 Back
 Home / Smart	 Smart
 3D	 3D
 123 / Q.Menu	 Shift + Ok
 Vol +	 Vol +
 Vol -	 Vol -
 Mute	 Mute
 P +	 Ch +
 P -	 Ch -

Originale	Sostituto
Ratio	 Format
List	 List
Q.Menu	 Shift + Menu
Subtitle	 Subt
Settings	 Shift + Options
AD / PIP	 Dual
>>	 >>
>>>	 >>I
Play	 Play
<<<	 <<<
<<	 I<<<
Rec	 Rec
Pause	 Pause
Stop / Live TV	 Stop
AV Mode	 Shift + AV
Text	 Text
FAV	 Shift + Pre Ch





Originale	Sostituto	Originale	Sostituto
Exit	 Exit	T.Opt	 Options
TV / PC	 +  Shift + Smart	Q.View	 D. Menu
Input	 AV	Energy Saving	 +  Shift + 3D
TV / Radio	 TV/R	9	 9
 Blue	 D	8	 8
 Yellow	 C	7	 7
 Green	 B	6	 6
 Red	 A	5	 5
0	 0	4	 4
AD	 +  Shift + Subt	3	 3
Search	 +  Shift + TV/R	2	 2
Live Menu	 Menu	1	 1
Recent	 Pre Ch	My APPS	 Media
Live Zoom	 Eject		
App	 +  Shift + Media		
Guide	 Guide		
Info	 Info		

Originale	Sostituto	Originale	Sostituto
T.Opt	 Options	9	 9
Q.View	 D. Menu	8	 8
Energy Saving	 +  Shift + 3D	7	 7
9	 9	6	 6
8	 8	5	 5
7	 7	4	 4
6	 6	3	 3
5	 5	2	 2
4	 4	1	 1
3	 3	My APPS	 Media
2	 2		
1	 1		

