







































































Originale	Sostituto	Originale	Sostituto
	Power		Power
	Cable		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List
	Info		Info
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute

Originale	Sostituto	Originale	Sostituto
	CH+		Ch +
	CH-		Ch -
	Home		Smart
	Bach		Back
	Exit		Exit
	Guide		Guide
	[::]		TV/R
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Mouse Up		>>
	Mouse Down		<<
	3D		3D
	Micro		Dual
	*		Menu





Originale		Sostituto		Originale		Sostituto	
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

