











































































Originale	Sostituto
 Power	 Power
 Input	 AV
 Digital/Analog	 TV/R
 Sync Menu	 Menu
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Exit	 Exit
 [=]/Text	 Text
 Red	 Red

Originale	Sostituto
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Netflix	 Media
 [i+]/[?]	 Info
 Home	 Smart
 Sleep	 Sleep
 Guide	 Guide
 Return	 Back
 Options	 Options
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -





	Originale	Sostituto	Originale	Sostituto
	Mute	 Mute		
	PR+	 Ch +		
	PR-	 Ch -		
	Recall	 Pre Ch		
	[...]	 Subt		
	Audio	 Dual		
	Title List	 List		
	<<	 <<		
	Play	 Play		
	>>	 >>		
	I<<	 I<<		
	Pause	 Pause		
	>>I	 >>I		
	Rec	 Rec		
	Stop	 Stop		
	[+]	 3D		

