




Originale	Sostituto
 Power	 Power
 E-Manual	 Shift + D. Menu
 [ ]/Ratio	 Dual
 Input	 AV
 Tv/Rad	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List
 Q.View	 Format

Originale	Sostituto
 3D	 3D
 Vol+	 Vol +
 Vol-	 Vol -
 FAV	 Pre Ch
 Mute	 Mute
 P+	 Ch +
 P-	 Ch -
 Menu	 Menu
 Home	 Smart
 Back	 Back
 My	 D. Menu
 Guide	 Guide
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Originale	Sostituto
OK	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Text	Text
Subtitle	Subt
Stop/Live Tv	Stop
T.Opt	Options
Play	Play
Pause	Pause
<<	<<
>>	>>
Rec	Rec
Info	Info
Simplink	Media
Saving Energy	Shift + 3D

Originale	Sostituto

