















































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 [ <> ]	 Format
 Mute	 Mute	 Zoom	 Eject
 TTX/MIX	 Text	 OK/Freeze	 Ok
 MM	 Media	 Up	 Up
 TV	 TV/R	 Down	 Down
 1	 1	 Right	 Right
 2	 2	 Left	 Left
 3	 3	 Menu	 Menu
 4	 4	 PR+	 Ch +
 5	 5	 PR-	 Ch -
 6	 6	 Vol+	 Vol +
 7	 7	 Vol-	 Vol -
 8	 8	 Red	 Red
 9	 9	 Green	 Green
 0	 0	 Yellow	 Yellow
 AV	 AV	 Blue	 Blue
 Swap	 Pre Ch	 [i]	 Info

Originale	Sostituto	Originale	Sostituto
 Power	 MUTE	 SHIFT	 TV
 Mute	 DVD	 SAT	 AUX
 TTX/MIX	 PLAY MODE	 REC MODE	 Play
 MM	 II	 ■	 Stop
 TV	 ⏩	 ⏮	 FF
 1	 SOUND	 AD	 SETTINGS
 2	 DUAL	 SUBT	 OPT
 3	 SEARCH	 PICTURE	 ECO
 4	 SLEEP	 FORMAT	 3D
 5	 TV/R	 ZOOM	 TIMER
 6	 E-MANUAL	 TEXT	 AV
 7	 D.MENU	 ▲	 MENU
 8	 TOP MENU	 ▶	 INFO
 9	 DISPLAY	 ◀	 OK
 0	 CLEAR	 ▼	 RETURN
 AV	 EXIT	 HOME	 BACK
 SWAP	 VOL +	 SMART	 CH +
	 VOL -	 APP	 CH -
	 Red	 MEDIA	 1
	 Green	 1	 2
	 Yellow	 2	 3
	 Blue	 3	 4
	 [i]	 4	 5
		 5	 6
		 6	 7
		 7	 8
		8	9
		9	0
		0	GUIDE
		AV	PRE-CH
		SWAP	A
			B
			C
			D
			Mandis SHOP
			www.mandis.tv





Originale	Sostituto
[?]	Smart
[♦]	Options
[+]	Back
[♪]	Dual
[ ]	List
[≡x]	Subt
PIP SEL	Shift + Format
PIP POS	Shift + 3D
PIP SIZE	3D
PAT	D. Menu
[⋮]	Guide

Originale	Sostituto

