





































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Tv/Video	 TV/R
 Sleep	 Sleep
 ◆ Bright	 Guide
 PIP	 3D
 Exit	 Exit
 Text	 Text
 Pre PG	 Pre Ch
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 PG+	 Ch +
 PG-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -

Originale	Sostituto
 Menu/Set	 Menu
 V.Size	 Eject
 MTS	 Media
 Sound	 Dual
 Picture	 Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Time	 AV
 Still	 Options



