








































































Originale		Sostituto		Originale		Sostituto	
	Power Tv		Power		Vol-		Vol -
	Source		AV		Prog+		Ch +
	1		1		Prog-		Ch -
	2		2		Red		Red
	3		3		Green		Green
	4		4		Yellow		Yellow
	5		5		Blue		Blue
	6		6		OK		Ok
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	[≡]		Text		Guide		Guide
	[...]		Subt		Options		Options
	Mute		Mute		Return/Back		Back
	Audio		Dual		[i+]		Info
	Vol+		Vol +		Home		Smart









































































Originale	Sostituto
 FAV	 Pre Ch
 Wide	 Format
 Sync Menu	 Menu
 Stop	 Stop
 Play	 Play
 >>	 >>
 <<	 <<
 Theatre	 TV/R
 >>	 >>
 <<	 <<
 Digital/Analog	 Sleep
 Exit	 Exit
 ?/i-Manual	 Shift + D. Menu
 Scene	 3D
 Top Menu	 Shift + Menu
 Menu	 D. Menu
 Internet Widgets	 Media

Originale	Sostituto
 Internet Video	 Eject










































































Originale		Sostituto		Originale		Sostituto	
	Power DVD		Power		Audio		Dual
	1		1		OK		Ok
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		Return/Back		Back
	7		7		Home		Smart
	8		8		[i+]		Info
	9		9		Play		Play
	0		0		>>		>>
	[...]		Subt		<<		<<
	Mute		Mute		Stop		Stop
	Vol+		Vol +		>>		>>
	Vol-		Vol -		<<		<<
	Prog+		Ch +		Top Menu		Shift + Menu
	Prog-		Ch -		Menu		Menu









































































Originale		Sostituto		Originale		Sostituto	
	Power BD		Power		OK		Ok
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		[i+]		Info
	6		6		Return/Back		Back
	7		7		Options		Options
	8		8		Home		Smart
	9		9		<<		<<
	0		0		>>		>>
	[≡]		Text		Play		Play
	[...]		Subt		I<<		I<<
	Audio		Dual		>>I		>>I
	Vol+		Vol +		Stop		Stop
	Vol-		Vol -		Menu		Menu
	Mute		Mute		Top Menu		Shift + Menu





Originale		Sostituto		Originale		Sostituto	
	Power AMP		Power		Audio		Dual
	Source		AV		OK		Ok
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		[i+]		Info
	6		6		Return/Back		Back
	7		7		Home		Smart
	8		8		Play		Play
	9		9		>>		>>
	0		0		<<		<<
	[≡]		Text		Stop		Stop
	[...]		Subt		>>		>>
	Vol+		Vol +		<<		<<
	Vol-		Vol -		Top Menu		Shift + Menu
	Mute		Mute		Menu		Menu

