




Originale		Sostituto		Originale		Sostituto	
	Power		Power		Down / PIP Pr		Down
	1		1		Right		Right
	2		2		Left		Left
	3		3		OK		Ok
	4		4		Input		AV
	5		5		Option		Options
	6		6		Fav Pr		Pre Ch
	7		7		Red		Red
	8		8		Green		Green
	9		9		Yellow		Yellow
	0		0		Blue		Blue
	Media		Media		Vol +		Vol +
	Audio / I/II		Dual		Vol -		Vol -
	Menu		Menu		Mute		Mute
	Guide		Guide		Pr +		Ch +
	Exit		Exit		Pr -		Ch -
	Up / PIP Pr Up		Up		[≡] / Text		Text



