



Originale	Sostituto
Power	Power
Coax	Smart
OPT	Options
Audio In	Dual
Bluetooth	Up
USB	Down
AUX	Media
Play	Play
Pause	Pause
Play/Pause	Ok
>	>>
>	Right
<	<<
<	Left
Vol+	Vol +
Vol-	Vol -
Mute	Mute

Originale	Sostituto
Audio Sync+	Ch +
Audio Sync-	Ch -
Bass+	1
Bass-	4
Surr	2
Night	5
Treble+	3
Treble-	6

