



Originale	Sostituto
 Power	 Power
 Pause	 Pause
 COAX	 Red
 Optical	 Green
 AUX	 Yellow
 USB	 Blue
 Bluetooth	 Smart
 HDMI Arc	 Media
 I<	 I<<
 Play	 Play
 >I	 >>I
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Bass+	 Up
 Bass-	 Down
 Treble+	 Ch +

Originale	Sostituto
 Treble-	 Ch -
 Voice	 Dual
 Movie	 Pre Ch
 Music	 Guide
 Audio Sync+	 Right
 Audio Sync-	 Left
 Night On	 3
 Off Night	 1

