







































































Originale		Sostituto		Originale		Sostituto	
	Source		AV / Input / RDS		[≡]/Text		Text / Goto
	Power		Power		Google Play		Display / Media
	Digital/Analog		Setup / OPT /		Netflix		Shift + Red / Netflix /
	Tv/Radio		TV/Radio /		Red		Red / Netflix / Search
	Sync Menu		Menu / Home		Green		Green / APP / Repeat
	Exit		Exit / Cancel / Clear		Yellow		Yellow / YouTube / Repeat
	1		1		Blue		Blue / Prime Video / Random
	2		2		Action Menu		D.Menu / Top
	3		3		Tv		Shift + 1
	4		4		Up		Up
	5		5		Guide		Guide / EPG / -/-
	6		6		Left		Left
	7		7		OK		OK
	8		8		Right		Right
	9		9		Back		Back / Return
	[i]/[?]		Info / Angle		Down		Down
	0		0		Home		Shift + Menu / Home





Originale	Sostituto
Discover	Picture / Format
Vol+	Vol+
Recall	Fav / Marker / PC
Prog+	CH+ / Page+
Vol-	Vol-
Mute	Mute / Dimmer
Prog-	CH- / Page-
Audio	Audio / Lang I/II
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
[...]	Subtitle / EQ
I<<	I<< / Preset-
Pause	Pause / Step / Freeze
>>I	>>I / Preset+
Help	Sleep / Timer
Rec	Rec / Rec Mode

Originale	Sostituto
Stop	Stop / Hold
Title List	Smart / List

