

















































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Vol -		Vol -
	Input		AV		P+		Ch +
	TV / Rad		TV/R		P-		Ch -
	Q.Menu		D. Menu		Mute		Mute
	Menu		Menu		1		1
	Guide		Guide		2		2
	Up		Up		3		3
	Right		Right		4		4
	Down		Down		5		5
	Left		Left		6		6
	OK		Ok		7		7
	Exit		Exit		8		8
	Return		Back		9		9
	Info		Info		0		0
	AV Mode		3D		List		List
	Fav / Mark		Pre Ch		Q.View		Smart
	Vol +		Vol +		Red		Red







Originale		Sostituto		Originale		Sostituto	
	Power		Power		5		5
	Input		AV		6		6
	Menu		Menu		7		7
	OK		Ok		8		8
	Up		Up		9		9
	Down		Down		0		0
	Right		Right				
	Left		Left				
	Page +		Ch +				
	Page -		Ch -				
	Vol +		Vol +				
	Vol -		Vol -				
	Mute		Mute				
	1		1				
	2		2				
	3		3				
	4		4				

