



| Originale | Sostituto |
|----------------------------------|------------------------|
| Speakers TV Audio Bravia Sync | Shift + Sound / Title |
| Power AV Bravia Sync | Shift + Power |
| Power | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| ♥ | Fav / Marker / PC |
| [≡] | Text / Goto |
| 0 | 0 |
| Enter | Guide / EPG / -/-- |
| Red | Red / Netflix / Search |

| Originale | Sostituto |
|-------------|-----------------------------|
| Green | Green / APP / Repeat |
| Yellow | Yellow / YouTube / Repeat |
| Blue | Blue / Prime Video / Random |
| Top Menu | D.Menu / Top |
| Up | Up |
| Left | Left |
| OK | OK |
| Right | Right |
| Return | Back / Return |
| Down | Down |
| Options | Setup / OPT / |
| Home/Menu | Menu / Home |
| Sound Mode | Sound / Title |
| I<</Preset- | I<< / Preset- |
| ← | Shift + Left |
| → | Shift + Right |
| >>I/Preset+ | >>I / Preset+ |





| Originale | Sostituto |
|-----------|---------------------------|
| Eject | Eject / Surround |
| Power | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| ♥ | Fav / Marker / PC |
| 0 | 0 |
| Enter | Guide / EPG / -/-- |
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |
| Yellow | Yellow / YouTube / Repeat |

| Originale | Sostituto |
|---------------|-----------------------------|
| Blue | Blue / Prime Video / Random |
| Top Menu | D.Menu / Top |
| Up | Up |
| Pop Up Menu | Smart / List |
| Left | Left |
| OK | OK |
| Right | Right |
| Return | Back / Return |
| Down | Down |
| Options/Tools | Setup / OPT / |
| Function | Info / Angle |
| Home/Menu | Menu / Home |
| Sound Mode | Sound / Title |
| I<</Preset- | I<< / Preset- |
| ← | Shift + Left |
| → | Shift + Right |
| >>I/Preset+ | >>I / Preset+ |





| Originale | Sostituto |
|-------------------------------|------------------------|
| Speakers TV Audio Bravia Sync | Sound / Title |
| Power AV Bravia Sync | Shift + Power |
| Power | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| ♥ Fav / Marker / PC | Fav / Marker / PC |
| [=] Text / Goto | Text / Goto |
| 0 | 0 |
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |

| Originale | Sostituto |
|-----------|-----------------------------|
| Yellow | Yellow / YouTube / Repeat |
| Blue | Blue / Prime Video / Random |
| Top Menu | D.Menu / Top |
| Up | Up |
| Left | Left |
| OK | OK |
| Right | Right |
| Return | Back / Return |
| Down | Down |
| Home/Menu | Menu / Home |
| [...] | Subtitle / EQ |
| Mute | Mute / Dimmer |
| Vol+ | Vol+ |
| Prog+ | CH+ / Page+ |
| Display | Display / Media |
| Vol- | Vol- |
| Prog- | CH- / Page- |



