







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Menu	 Menu
 TV / AV	 AV	 ARC	 Back
 Open / Close	 Eject	 Exit	 Exit
 Multimedia	 Media	 Up	 Up
 List	 List	 Down	 Down
 [=] / Text	 Text	 Right	 Right
 PSM	 Shift + Format	 Left	 Left
 SSM	 Shift + Dual	 OK	 Ok
 I/II / Audio	 Dual	 Red / Disc Menu	 Red
 Stop	 Stop	 Green / Title	 Green
 Play	 Play	 Yellow / Display	 Yellow
 Pause / Step	 Pause	 Blue / Return	 Blue
 I<<	 I<<	 Vol +	 Vol +
 >>I	 >>I	 Vol -	 Vol -
 <<	 <<	 Mute	 Mute
 >>	 >>	 PR +	 Ch +
 >I< / Repeat	 Shift + Text	 PR -	 Ch -

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Menu	 Menu
 TV / AV	 AV	 ARC	 Back
 Open / Close	 Eject	 Exit	 Exit
 Multimedia	 Media	 Up	 Up
 List	 List	 Down	 Down
 [=] / Text	 Text	 Right	 Right
 PSM	 Shift + Format	 Left	 Left
 SSM	 Shift + Dual	 OK	 Ok
 I/II / Audio	 Dual	 Red / Disc Menu	 Red
 Stop	 Stop	 Green / Title	 Green
 Play	 Play	 Yellow / Display	 Yellow
 Pause / Step	 Pause	 Blue / Return	 Blue
 I<<	 I<<	 Vol +	 Vol +
 >>I	 >>I	 Vol -	 Vol -
 <<	 <<	 Mute	 Mute
 >>	 >>	 PR +	 Ch +
 >I< / Repeat	 Shift + Text	 PR -	 Ch -



