

















































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Exit	 Exit
 Mute	 Mute	 ▲	 >>
 1	 1	 ▼	 <<
 2	 2	 CH ▲	 Ch +
 3	 3	 CH ▼	 Ch -
 4	 4	 CH ▲	 Up
 5	 5	 CH ▼	 Down
 6	 6	 VOL ►	 Right
 7	 7	 VOL ◀	 Left
 8	 8	 OK	 Ok
 9	 9	 VOL ►	 Vol +
 0	 0	 VOL ◀	 Vol -
 Recall	 Back	 SAT	 Smart
 Info	 Info	 FAV	 Pre Ch
 Tv/Radio	 TV/R	 Tv/AV	 AV
 EPG	 Guide	 PAL/NTSC	 Format
 Menu	 Menu	 Pause	 Pause

Originale	Sostituto	Originale	Sostituto
 Exit	 Exit	 Exit	 Exit
 ▲	 >>	 ▲	 >>
 ▼	 <<	 ▼	 <<
 CH ▲	 Ch +	 CH ▲	 Ch +
 CH ▼	 Ch -	 CH ▼	 Ch -
 CH ▲	 Up	 CH ▲	 Up
 CH ▼	 Down	 CH ▼	 Down
 VOL ►	 Right	 VOL ►	 Right
 VOL ◀	 Left	 VOL ◀	 Left
 OK	 Ok	 OK	 Ok
 VOL ►	 Vol +	 VOL ►	 Vol +
 VOL ◀	 Vol -	 VOL ◀	 Vol -
 SAT	 Smart	 SAT	 Smart
 FAV	 Pre Ch	 FAV	 Pre Ch
 Tv/AV	 AV	 TV/AV	 AV
 PAL/NTSC	 Format	 PAL/NTSC	 Format
 Pause	 Pause	 Pause	 Pause





Originale		Sostituto	
	UHF		Media
	Play		Play
	Red/Audio		Red
	Green/Position		Green
	Yellow/[...]		Yellow
	Blue/Audio L/R		Blue

Originale		Sostituto	

