















	Originale	Sostituto	
	Power		Power
	Input		AV
	Tv/Rad		TV/R
	Guide		Guide
	Info		Info
	Ratio		Format
	AV Mode		Shift + AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

	Originale	Sostituto	
	List		List
	Q.View		Options
	Menu		Menu
	Exit		Exit
	Return		Back
	Text		Text
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	FAV		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	P+		Ch +
	P-		Ch -





Originale	Sostituto	Originale	Sostituto
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 [=o]/Subpage	 Smart		
 [=+]/Hold	 3D		
 [=i]/Index	 D. Menu		
 [=?]/Reveal	 Media		
 I/II	 Dual		
 Subtitle	 Subt		
 Sleep	 Sleep		

Originale	Sostituto

