







































































Originale	Sostituto	Originale	Sostituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	M		Menu
	E		Exit
	i		Info
	Rec		Rec
	Pause		Pause
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<<		<<
	Stop		Stop
	Play		Play
	>>		>>
	Mute/Timer		Mute
	[ ]		Subt
	T		TV/R
	Guide/000		Guide
	V≡/LP		Format









































































Originale	Sostituto	Originale	Sostituto
[ * ]/SV	3D		
Sound	Dual		









Originale	Sostituto	Originale	Sostituto
	Power		Power
	[ ]		Subt
	Mute/Timer		Mute
	Guide/000		Guide
	V= / LP		Format
	[ * ] / SV		3D
	Sound		Dual
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	M		Menu
	E		Exit
	T		TV/R
	i		Info
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<<		<<
	Stop		Stop
	Play		Play
	>>		>>











































































Originale		Sostituto		Originale		Sostituto	
	Pause		Pause				
	Rec		Rec				





Originale		Sostituto		Originale		Sostituto	
	Power		Power		M		Menu
	[ ]		Subt		E		Exit
	Mute/Timer		Mute		T		TV/R
	Guide/000		Guide		OK		Ok
	V= / LP		Format		Up		Up
	[ * ] / SV		3D		Down		Down
	Sound		Dual		Right		Right
	1		1		Left		Left
	2		2		Red		Red
	3		3		Green		Green
	4		4		Yellow		Yellow
	5		5		Blue		Blue
	6		6		<<		<<
	7		7		Stop		Stop
	8		8		Play		Play
	9		9		>>		>>
	0		0		Pause		Pause

