



	Originale	Sostituto		Sostituto
	Power	Power		
	Mute	Mute		
	AUX	Media		
	D.IN	Smart		
	Woofer Level	Ch +		
	Woofer Level	Ch -		
	Vol+	Vol +		
	Vol-	Vol -		
	Play	Play		
	Pause	Pause		
	>>I	>>I		
	I<<	I<<		
	Tv Sound	TV/R		
	Bluetooth	Options		
	Sound Effect	Dual		
	Auto Power	Sleep		
	Bluetooth	Shift + Power		

	Originale	Sostituto		Sostituto
	USB	AV		



Power