







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		△		Smart
	Ambilight		3D		Red		Red
	Source		AV		Green		Green
	Settings		Options		Yellow		Yellow
	Top Picks		D. Menu		Blue		Blue
	Search		TV/R		Vol+		Vol +
	TV/Exit		Exit		Vol-		Vol -
	Tv Guide		Guide		Mute		Mute
	Windows		Info		Netflix		Media
	List		List		≡+		Ch +
	Up		Up		≡-		Ch -
	Down		Down		1		1
	Right		Right		2		2
	Left		Left		3		3
	OK		Ok		4		4
	←		Back		5		5
	+		Format		6		6





Originale		Sostituto		Originale		Sostituto	
	7		7				
	8		8				
	9		9				
	0		0				
	Subtitle		Subt				
	Text		Text				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				
	<<		<<				
	Play		Play				
	>>		>>				

