



Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Right	 Right
 3D	 3D	 Left	 Left
 Tv Input	 TV/R	 OK	 Ok
 AV Input	 AV	 Red	 Red
 Menu	 Menu	 Green	 Green
 [+]/Aspect	 Format	 Yellow	 Yellow
 N	 D. Menu	 Blue	 Blue
 (<>)/Surround	 Dual	 [=]/Text	 Text
 i	 Info	 [=♦]/STTL	 Subt
 X/Exit	 Exit	 [=i]/Index	 List
 Internet	 Smart	 [=+]/Hold	 Sleep
 Viera Tools	 Media	 1	 1
 Guide	 Guide	 2	 2
 Option	 Options	 3	 3
 Return/Back	 Back	 4	 4
 Up	 Up	 5	 5
 Down	 Down	 6	 6

Originale	Sostituto	Originale	Sostituto
 Right	 Right	 Left	 Left
 Left	 Left	 OK	 Ok
 OK	 Ok	 Red	 Red
 Red	 Red	 Green	 Green
 Green	 Green	 Yellow	 Yellow
 Yellow	 Yellow	 Blue	 Blue
 Blue	 Blue	 [=]/Text	 Text
 [=]/Text	 Text	 [=♦]/STTL	 Subt
 [=♦]/STTL	 Subt	 [=i]/Index	 List
 [=i]/Index	 List	 [=+]/Hold	 Sleep
 [=+]/Hold	 Sleep	 1	 1
 1	 1	 2	 2
 2	 2	 3	 3
 3	 3	 4	 4
 4	 4	 5	 5
 5	 5	 6	 6





	Originale	Sostituto		Sostituto
	7		7	
	8		8	
	9		9	
	0		0	
	Last View		Pre Ch	
	Vol+		Vol +	
	Vol-		Vol -	
	Mute		Mute	
	CH+		Ch +	
	CH-		Ch -	
	Second Power		Shift + Power	
	Programme Up		Shift + Ch +	
	Programme		Shift + Ch -	
	<</ <<		<<	
	Play		Play	
	>>/>>		>>	
	Stop		Stop	

	Originale	Sostituto
	Pause/Step	
	Rec	

