














































Originale	Sostituto
 Power	 Power
 Select Drive	 List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Last View	 Pre Ch
 Radio/Tv	 TV/R
 CH/Page+	 Ch +
 CH/Page-	 Ch -
 Internet	 Smart

Originale	Sostituto
 Netflix	 Media
 I<< Skip	 I<<
 Skip >>I	 >>I
 << Slow/Search	 <<
 Slow/Search >>	 >>
 Stop	 Stop
 Pause/PAUSE Live	 Pause
 Play	 Play
 Rec	 Rec
 i/Status	 Info
 X/Exit	 Exit
 Video Menu	 D. Menu
 Guide	 Guide
 Function Menu	 Menu
 Option	 Options
 Return	 Back
 Up	 Up





Originale	Sostituto
	 Down
	 Right
	 Left
	 Ok
	 Red
	 Green
	 Yellow
	 Blue
	 +  Shift + Rec
	 TEXT Text
	 SUBT Subt
	 SLEEP Sleep
	 FORMAT Format
	 3D 3D
	 DUAL Dual
	 AV AV
	 Eject

Originale	Sostituto
	 +  Shift + Left
	 +  Shift + Right
	 +  Shift + Power
	 +  Shift + AV
	 Vol +
	 Vol -
	 +  Shift + Ch +
	 +  Shift + Ch -

