






































































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 (i)	 Info
 AV	 AV
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Originale	Sostituto
 Blue	 Blue
 TV	 TV/R
 Menu	 Menu
 [≡]/Top Menu	 Text
 Back	 Back
 P+	 Ch +
 P-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 ↑/[+]	 Pre Ch
 F.T/L	 Options
 [?]	 3D





Originale		Sostituto		Originale	Sostituto
	Power		Power		
	(i)		Info		
	Menu		Menu		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	Top Menu	 + 	Shift + Menu		
	Back		Back		
	↑/[+]		Pre Ch		
	↓/[]		Guide		
	<<		<<		
	Play		Play		
	>>		>>		
	Stop		Stop		
	Pause		Pause		



