

















































| Originale  | Sostituto   |
|--|---|
|  Power    |  Power         |
|  3D       |  3D            |
|  1        |  1             |
|  2        |  2             |
|  3        |  3             |
|  4        |  4             |
|  5        |  5             |
|  6        |  6             |
|  7        |  7             |
|  8        |  8             |
|  9       |  9            |
|  0      |  0           |
|  ECO    |  Shift + 3D |
|  Source |  AV          |
|  Vol +  |  Vol +       |
|  Vol -  |  Vol -       |
|  Mute   |  Mute        |

| Originale  | Sostituto   |
|--|---|
|  Info           |  Info            |
|  P +            |  Ch +            |
|  P -            |  Ch -            |
|  W              |  Shift + Smart   |
|  Smart TV       |  Smart           |
|  @              |  Media           |
|  Menu           |  Menu            |
|  Up             |  Up              |
|  Down           |  Down            |
|  Right / Zoom + |  Right           |
|  Left / Zoom - |  Left           |
|  OK           |  Ok            |
|  Back         |  Back          |
|  Exit         |  Exit          |
|  Option       |  Options       |
|  USB          |  Shift + Media |
|  TV           |  TV/R          |



