









































Originale	Sostituto	Originale	Sostituto
Standby	Power	Info	Info
Backlight	D. Menu	Up	Up
Setup	Options	Down	Down
Edit	Exit	Right	Right
Target	3D	Left	Left
Repeat	Text	Enter	Ok
Subtitle	Subt	<<	<<
Video Out	Sleep	>>	>>
Display	Shift + Info	I<<	I<<
Zoom	Eject	>>I	>>I
Audio/Stream	Dual	Play	Play
Digest Photo	Menu	Pause	Pause
Mode Photo	TV/R	Stop	Stop
Slide Time	Media	4:3/16:9	Format
Rotate	Back	Source	AV
Home	Smart	1	1
CH/Sub-Audio	List	2	2

Originale	Sostituto	Originale	Sostituto
Standby	Power	Info	Info
Backlight	D. Menu	Up	Up
Setup	Options	Down	Down
Edit	Exit	Right	Right
Target	3D	Left	Left
Repeat	Text	Enter	Ok
Subtitle	Subt	<<	<<
Video Out	Sleep	>>	>>
Display	Shift + Info	I<<	I<<
Zoom	Eject	>>I	>>I
Audio/Stream	Dual	Play	Play
Digest Photo	Menu	Pause	Pause
Mode Photo	TV/R	Stop	Stop
Slide Time	Media	4:3/16:9	Format
Rotate	Back	Source	AV
Home	Smart	1	1
CH/Sub-Audio	List	2	2





	Originale	Sostituto		Sostituto
	3		3	
	4		4	
	5		5	
	6		6	
	7		7	
	8		8	
	9		9	
	0		0	
	+10			
	Time Search		Guide	
	Vol+		Vol +	
	Vol-		Vol -	
	Mute		Mute	
	EQ Type		Ch +	
	EQ On/Off		Ch -	
	Movie		Red	
	Music		Green	

	Originale	Sostituto		Sostituto
	Photo		Yellow	
	File		Blue	

