






































Originale	Sostituto
 Power	 Power
 Viera Tools	 Smart
 Tv Input	 TV/R
 AV Input	 AV
 Menu	 Menu
 Text	 Text
 [≡◆]/STTL	 Subt
 Guide	 Guide
 i	 Info
 X/Exit	 Exit
 Option	 Options
 Back/Return	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok

Originale	Sostituto
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 [+]/Aspect	 3D
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7





Originale		Sostituto	
8 tuv	8	8	8
9 wxyz	9	9	9
0	0	0	0
STILL	Still	APP MEDIA	Media
LAST VIEW	Last View	FAV PRE-CH	Pre Ch

Originale		Sostituto	

