































	Originale	Sostituto		Sostituto
	Power		Power	Power
	ShowView		Smart	Smart
	Rec Check		3D	3D
	Ext Link		Text	Text
	Rec		Rec	Rec
	1		1	1
	2		2	2
	3		3	3
	4		4	4
	5		5	5
	6		6	6
	7		7	7
	8		8	8
	9		9	9
	0		0	0
	-/--		Guide	Guide
	AV/Input Select		AV	AV

	Originale	Sostituto		Sostituto
	Tracking/V-Lock+		Ch +	Ch +
	Tracking/V-Lock-		Ch -	Ch -
	Vol+		Vol +	Vol +
	Vol-		Vol -	Vol -
	I<< Index		I<<	I<<
	Index >>I		>>I	>>I
	<<		<<	<<
	>>		>>	>>
	Stop		Stop	Stop
	Pause/Step		Pause	Pause
	Play		Play	Play
	Prog Play		Options	Options
	Menu		Menu	Menu
	Display		Info	Info
	Exit		Exit	Exit
	Up		Up	Up
	Down		Down	Down













































































































































Originale	Sostituto	Originale	Sostituto
 Right	 Right		
 Left	 Left		
 Enter	 Ok		
 Prog/Check	 Sleep		
 Timer	 Shift + AV		
 Output	 TV/R		
 AV Link	 Media		
 Audio	 Dual		
 Tv Aspect/Off	 Format		
 Music w/Picture	 List		
 A/Cancel Reset	 Red		
 B/I-Timer	 Green		
 C/SP/LP/EP	 Yellow		
 D/VPS/PDC	 Blue		





































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Vol+	 Vol +
 Rec Check	 3D	 Vol-	 Vol -
 Ext Link	 Media	 I<< Skip	 I<<
 1	 1	 Skip >>I	 >>I
 2	 2	 << Slow/Search	 <<
 3	 3	 Slow/Search >>	 >>
 4	 4	 Stop	 Stop
 5	 5	 Pause/Step	 Pause
 6	 6	 Play	 Play
 7	 7	 Top Menu/Direct Navigator	 Menu
 8	 8	 Play List	 List
 9	 9	 Display	 Info
 0	 0	 Return	 Back
 >10	 Guide	 Up	 Up
 AV/Input Select	 AV	 Down	 Down
 Tracking/V-Lock/C	 Ch +	 Right	 Right
 Tracking/V-Lock/C	 Ch -	 Left	 Left

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Vol+	 Vol +
 Rec Check	 3D	 Vol-	 Vol -
 Ext Link	 Media	 I<< Skip	 I<<
 1	 1	 Skip >>I	 >>I
 2	 2	 << Slow/Search	 <<
 3	 3	 Slow/Search >>	 >>
 4	 4	 Stop	 Stop
 5	 5	 Pause/Step	 Pause
 6	 6	 Play	 Play
 7	 7	 Top Menu/Direct Navigator	 Menu
 8	 8	 Play List	 List
 9	 9	 Display	 Info
 0	 0	 Return	 Back
 >10	 Guide	 Up	 Up
 AV/Input Select	 AV	 Down	 Down
 Tracking/V-Lock/C	 Ch +	 Right	 Right
 Tracking/V-Lock/C	 Ch -	 Left	 Left




























Originale	Sostituto
 Enter	 Ok
 Timer	 Shift + AV
 Quick Replay	 D. Menu
 Output	 TV/R
 Subtitle	 Subt
 Audio	 Dual
 Angle/Page	 Smart
 Music w/Picture	 Pre Ch
 Play Mode	 Shift + Play
 Zoom	 Eject
 Repeat	 Text
 Position	 Options
 A/Cancel Reset	 Red
 B/Cinema	 Green
 C/Group	 Yellow
 D/Setup	 Blue

Originale	Sostituto





Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 GUIDE
 AV	 AV
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -

Originale	Sostituto
 Tv Aspect	 Format
 A	 Red
 B	 Green
 C	 Yellow
 D	 Blue

