



Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Play	 Play
 Sleep	 Sleep	 Pause	 Pause
 CD	 1	 >>I	 >>I
 iPod	 2	 I<<	 I<<
 AUX	 3	 Stop	 Stop
 Tuner	 4	 Option	 Options
 USB	 6	 Back	 Back
 Folder Down	 Ch -	 X	 Media
 Folder Up	 Ch +	 Display	 Info
 ←	 <<	 Vol+	 Vol +
 →	 >>	 Vol-	 Vol -
 Up	 Up	 Mute	 Mute
 Down	 Down	 << Tuning	 Red
 Right	 Right	 Tuning >>	 Green
 Left	 Left	 < Preset	 Yellow
 Enter	 Ok	 Memory	 TV/R
 Menu	 Menu	 Preset >	 Blue

Originale	Sostituto	Originale	Sostituto
 Play	 Play	 Play	 Play
 Pause	 Pause	 Pause	 Pause
 >>I	 >>I	 >>I	 >>I
 I<<	 I<<	 I<<	 I<<
 Stop	 Stop	 Stop	 Stop
 Option	 Options	 Option	 Options
 Back	 Back	 Back	 Back
 X	 Media	 X	 Media
 Display	 Info	 Display	 Info
 Vol+	 Vol +	 Vol+	 Vol +
 Vol-	 Vol -	 Vol-	 Vol -
 Mute	 Mute	 Mute	 Mute
 << Tuning	 Red	 << Tuning	 Red
 Tuning >>	 Green	 Tuning >>	 Green
 < Preset	 Yellow	 < Preset	 Yellow
 Memory	 TV/R	 Memory	 TV/R
 Preset >	 Blue	 Preset >	 Blue

