








































Originale	Sostituto
 Power	 Power
 Sleep	 Sleep / Timer
 Mute	 Mute / Dimmer
 Mode	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 Eject/Nicam2	 Eject / Surround
 Eject/Nicam2	 Sound / Title
 4	 4
 5	 5
 6	 6
 TXT/MIX	 Text / Goto
 Play/Pause	 Play / Slow
 Play/Pause	 Pause / Step / Freeze
 7	 7
 8	 8

Originale	Sostituto
 9	 9
 Stop/Exit/Cancel	 Exit / Cancel / Clear
 Stop/Exit/Cancel	 Stop / Hold
 -/--	 Guide / EPG / -/--
 0	 0
 Back	 Back / Return
 SYS Menu	 Menu / Home
 Rec	 Rec / Rec Mode
 Up	 Up
 CH+	 CH+ / Page+
 DTV/Radio	 TV/Radio /
 Left	 Left
 Enter	 OK
 Right	 Right
 Vol-	 Vol-
 Down	 Down
 CH-	 CH- / Page-





Originale	Sostituto
Vol+	Vol+
Return	Shift + Back / Return
Menu DVD	D.Menu / Top
Setup	Setup / OPT /
Display	Display / Media
Search/FAV	Shift + Red / Netflix /
Search/FAV	Fav / Marker / PC
Slow/EPG	Shift + Play /
Slow/EPG	Shift + Guide / EPG / --
Language/Info	Audio / Lang I/II
Language/Info	Info / Angle
Zoom/List	Zoom / Size
Zoom/List	Smart / List
Red/Angle	Red / Netflix / Search
Red/Angle	Shift + Info / Angle
Green/Program	Green / APP / Repeat
Green/Program	Shift + TV/Radio / Program

Originale	Sostituto
Yellow/Repeat	Shift + Green / APP /
Yellow/Repeat	Yellow / YouTube / Repeat
Blue/A-B	Blue / Prime Video / Random
Blue/A-B	Shift + Yellow / YouTube /
<</Hold	Shift + Stop /
<</Hold	<< / Tune-
>>/Index	>> / Tune+
I<</Size	I<< / Preset-
I<</Size	Shift + Zoom /
>>I/Reveal	>>I / Preset+
Subtitle	Subtitle / EQ
Title/Subpage	Shift + Sound / Title
FAV-	Shift + Down
FAV+	Shift + Up

