

































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Source	 AV
 MyEPG	 Pre Ch
 V-Format	 Format
 Wide	 3D
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Text	 Text

Originale	Sostituto
 Menu	 Menu
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 List	 List
 Guide	 Guide
 Exit	 Exit
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 i	 Info





Originale	Sostituto	Originale	Sostituto
 OPT+	 Options		
 P+	 Ch +		
 P-	 Ch -		
 m@p	 Media		
 Audio	 Dual		
 SUB	 Subt		
 TV/Radio	 TV/R		
 Play	 Play		
 Pause	 Pause		
 Rec	 Rec		
 Stop	 Stop		
 <<	 <<		
 >>	 >>		
 I<<	 I<<		
 >>I	 >>I		

