


































































Originale	Sostituto	Originale	Sostituto
	Power		Power
	Imagen		Format
	Sonido		Dual
	Tamaño		3D
	Guía		Guide
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
	DTV/Radio		TV/R
	Fuente		AV
	Info		Info
	Menu		Menu
	Salir		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Audio		Shift + Dual
	Play		Play
	Pause/TS		Pause
	Stop		Stop
	Rec		Rec
	Sub.		Subt
	List		List
	FAV.		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute





Originale		Sostituto		Originale		Sostituto	
	P+		Ch +				
	P-		Ch -				
	Text		Text				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Sleep		Sleep				
	Recall		Back				

