





































Originale	Sostituto
	 Power
	 TV / DTV
	 Source
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Recall
	 0
	 Info
	 FAV
	 Picture

Originale	Sostituto
	 Sound / Title
	 Vol+
	 CH+ / Page+
	 Vol-
	 Mute / Dimmer
	 CH- / Page-
	 Menu / Home
	 Guide / EPG / -/-
	 Up
	 Left
	 OK
	 Right
	 Down
	 Audio / Lang I/II
	 Pause / Step / Freeze
	 Zoom / Size
	 Exit / Cancel / Clear





Originale	Sostituto
Radio / Browse	TV/Radio /
T.Shift / Rotate	D.Menu / Top
Lang / Page up	Shift + Audio / Lang I/II
Lang / Page up	Shift + CH+ /
Subtitle / Page down	Subtitle / EQ
Subtitle / Page down	Shift + CH- /
DMP	Smart / List
PVR	Display / Media
Play / Pause	Play / Slow
Stop	Stop / Hold
Red / <<<	Red / Netflix / Search
Red / <<<	<<< / Tune-
Green / >>>	Green / APP / Repeat
Green / >>>	>>> / Tune+
Yellow / I<<<	Yellow / YouTube / Repeat
Yellow / I<<<	I<<< / Preset-
Blue / >>>I	Blue / Prime Video / Random

Originale	Sostituto
Blue / >>>I	>>>I / Preset+
Text	Text / Goto
Size	Shift + Zoom /
Reveal	Shift + Smart / List
Cancel	Shift + Exit / Cancel / Clear
Hold / Sleep	Sleep / Timer
Hold / Sleep	Shift + Stop /
Index	Shift + Display / Media
Sub.Code	Eject / Surround
Mix	Shift + Text /

