



Originale		Sostituto		Originale		Sostituto	
	Power		Power		Mute		Mute
	Netflix		Media		Home		Smart
	Source		AV		P +		Ch +
	1		1		P -		Ch -
	2		2		Menu		Menu
	3		3		Q.Menu		D. Menu
	4		4		Up		Up
	5		5		Right		Right
	6		6		Down		Down
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Back		Back
	0		0		Exit		Exit
	TV		TV/R		i		Info
	Recall		Pre Ch		Video		Shift + Smart
	V +		Vol +		EPG		Guide
	V -		Vol -		YouTube		Shift + Media





	Originale	Sostituto		Originale	Sostituto
	Fav 2	 Shift + Pre Ch			
	TXT	 Text			
	Lang.	 Dual			
	Subt.	 Subt			
	Aspect	 Format			
	<<	 <<			
	<<	 I<<			
	Pause	 Pause			
	>>	 >>			
	>>	 >>I			
	Red	 Rec			
	Play	 Play			
	Stop	 Stop			
	Red	 Red			
	Green	 Green			
	Yellow	 Yellow			
	Blue	 Blue			

