







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Right		Right
	Source		AV		Down		Down
	TV		TV/R		Left		Left
	Quick		Shift + Pre Ch		OK		Ok
	ECO		Shift + 3D		Red		Red
	List		List		Green		Green
	Vol+		Vol +		Yellow		Yellow
	Vol-		Vol -		Blue		Blue
	AD		Shift + Subt		1		1
	Mute		Mute		2		2
	P+		Ch +		3		3
	P-		Ch -		4		4
	Menu		Menu		5		5
	Guide		Guide		6		6
	Exit		Exit		7		7
	Back		Back		8		8
	Up		Up		9		9



