



Originale	Sostituto
	Power
	AV / Input / RDS
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Info / Angle
	0
	Guide / EPG / -/--
	Vol+
	Mute / Dimmer
	Menu / Home

Originale	Sostituto
	CH+ / Page+
	Vol-
	Shift + Green / APP /
	CH- / Page-
	Up
	Left
	OK
	Right
	Back / Return
	Down
	Exit / Cancel / Clear
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Audio / Lang I/II
	Subtitle / EQ



