







































































Originale	Sostituto
 Standby	 Power
 Mute	 Mute
 ATV	 Smart
 Tv/Radio	 TV/R
 Tv Guide	 Guide
 USB	 Media
 Rec	 Rec
 I<<	 I<<
 >>I	 >>I
 Stop	 Stop
 <<	 <<
 >>	 >>
 Play	 Play
 Pause	 Pause
 Rec List	 List
 AV/Source	 AV
 i/Info	 Info

Originale	Sostituto
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0





Originale	Sostituto
 Back	 Back
 FAV	 Pre Ch
 Vol+	 Vol +
 Vol-	 Vol -
 Subtitle	 Subt
 Aspect	 3D
 Audio	 Dual
 Sleep	 Sleep
 CH+	 Ch +
 CH-	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Text	 Text
 Index	 Options
 Reveal	 D. Menu

Originale	Sostituto
 Power/Display	 Shift + Power
 P.Mode	 Shift + Format
 Size	 Format
 Hold/Lang	 Shift + Dual
 S.Mode	 Eject

