




Originale	Sostituto	Originale	Sostituto
Power	Power	Equalizer	Options
Open/Close	Eject	Special EQ	Dual
Vol+	Vol +	( i )	Info
Vol-	Vol -	1	1
F	Menu	2	2
Mute	Mute	3	3
Preset/Folder Up	Ch +	4	4
Prset/Folder Down	Ch -	5	5
Jukebox/Memor	Red	6	6
Auto Dj	Green	7	7
Delete	Blue	8	8
Repeat	Text	9	9
Stop	Stop	0	0
>>I/Tuning+	>>I	Clock	Shift + AV
I<</Tuning-	I<<	Alarm	Smart
Play / Pause	Pause	Voice Canceller	Yellow
Play / Pause	Play	Sleep	Sleep

Originale	Sostituto	Originale	Sostituto
Equalizer	Options	Settings	Options
Special EQ	Dual	Dual	Dual
( i )	Info	Info	Info
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Clock	Shift + AV	Shift + AV	Shift + AV
Alarm	Smart	Home Smart	Smart
Voice Canceller	Yellow	Yellow	Yellow
Sleep	Sleep	Sleep	Sleep





Originale		Sostituto	
	RDS/Set		Media
	Key Changer #		TV/R
	Key Changer b		3D
	Mic Echo		Subt
	PTY		AV
	Vocal Effects		Format
	USB Rec		Rec

Originale		Sostituto	

