





































Originale	Sostituto
 Power	 Power
 Mute	 Mute / Dimmer
 Rec	 Rec / Rec Mode
 TV Sys.	 D.Menu / Top
 Browser	 Display / Media
 Copy	 Picture / Format
 Music	 Smart / List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Repeat	 Shift + Green / APP / Repeat

Originale	Sostituto
 0	 0
 Info	 Info / Angle
 <<	 << / Tune-
 Vol -	 Vol-
 Vol +	 Vol+
 I<<	 I<< / Preset-
 >>	 >> / Tune+
 Play / Pause	 Play / Slow
 Play / Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 >>I	 >>I / Preset+
 Home	 Shift + Menu /
 Up	 Up
 Return	 Back / Return
 Left	 Left
 Enter	 OK
 Right	 Right





Originale	Sostituto
Menu	Menu / Home
Down	Down
Setup	Setup / OPT /
Time Shift	Sleep / Timer
Slow I>	Shift + Play /
A-B	Shift + YouTube /
Goto	Shift + Text /
Zoom	Zoom / Size
Audio	Audio / Lang I/II
Subtitle	Subtitle / EQ
Angle	Shift + Info / Angle
Red	Red / Netflix / Search
Green / EPG	Green / APP / Repeat
Green / EPG	Guide / EPG / -/-
Yellow / Text	Text / Goto
Yellow / Text	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random

Originale	Sostituto

