



































	Originale	Sostituto	Originale	Sostituto
	Standby			Power
	Pic Muting			Mute / Dimmer
	Freeze			Pause / Step / Freeze
	Input			AV / Input / RDS
	Menu			Menu / Home
	Up			Up
	Left			Left
	Enter			OK
	Right			Right
	Reset			Exit / Cancel / Clear
	Down			Down
	Vol+			Vol+
	Keystone			Smart / List
	D-Zoom+			CH+ / Page+
	Vol-			Vol-
	APA			Display / Media
	D-Zoom-			CH- / Page-

