







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Right		Right
	Mute		Mute		Down		Down
	Rec List		Smart		Left		Left
	CH / List		Media		OK		Ok
	Subtitle		Subt		Menu		Menu
	Repeat		Shift + Text		Exit		Exit
	Rec		Rec		1		1
	Stop		Stop		2		2
	I<<		I<<		3		3
	>>I		>>I		4		4
	Pause		Pause		5		5
	Play		Play		6		6
	<<		<<		7		7
	>>		>>		8		8
	Source		AV		9		9
	Display		Info		0		0
	Up		Up		Recall		Back





Originale	Sostituto
	Pre Ch
	Vol +
	Vol -
	Format
	Shift + Dual
	Guide
	Sleep
	Ch +
	Ch -
	Red
	Green
	Yellow
	Blue
	Text
	Shift + Exit
	TV/R
	Dual

Originale	Sostituto
	Shift + Pause
	Eject
	Shift + Subt
	Shift + Info

