








































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 FAV	 Pre Ch
 Recall	 Back
 Game	 Media
 Auto	 Smart
 Info	 Info

Originale	Sostituto
 Menu	 Menu
 EPG	 Guide
 Exit	 Exit
 CH+	 Ch +
 CH-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Zoom	 Eject





	Originale	Sostituto
	Lan/Audio	 Dual
	Text	 Text
	Tv/Radio	 TV/R
	Subtitle	 Subt
	Play	 Play
	Pause	 Pause
	<<	 <<
	>>	 >>

Originale	Sostituto

