














Originale	Sostituto
 Power	 Power
 Mute	 Mute
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Nicam / A2	 Dual
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide

Originale	Sostituto
 Recall	 Pre Ch
 FAV	 Shift + Pre Ch
 Fav +	 Shift + Up
 Fav -	 Shift + Down
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Source	 AV
 Info	 Info
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Menu	 Menu
 Exit	 Exit





Originale	Sostituto	Originale	Sostituto
 Vol +	 Vol +	 Repeat	 Shift + Text
 Vol -	 Vol -	 Auto	 Smart
 Media	 Media	 A-B	 Back
 TV / Radio	 TV/R	 Aspect	 Format
 CH +	 Ch +		
 CH -	 Ch -		
 Play/Pause / Text	 Play		
 Play/Pause / Text	 Pause		
 Play/Pause / Text	 Text		
 << / Size	 <<		
 << / Size	 3D		
 >> / Reveal	 >>		
 Stop / Hold	 Stop		
 I<< / Index	 I<<		
 >>I / Subpage	 >>I		
 Cancel	 Shift + Exit		
 Subtitle	 Subt		

*(This table is a duplicate of the previous one and is intentionally blank in the original image)*

