










Originale	Sostituto
Power	Power
Audio I/II	Dual
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Sleep	Sleep
Recall	Back
Exit	Exit
Menu	Menu

Originale	Sostituto
Source	AV
Info	Info
Up	Up
Right	Right
Down	Down
Left	Left
OK	Ok
Vol +	Vol +
Vol -	Vol -
CH +	Ch +
CH -	Ch -
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
P.Mode	Format
S.Mode	Shift + Dual





Originale		Sostituto		Originale		Sostituto	
	P.Size		Eject				
	Subtitle		Subt				
	Play/Pause / TS		Play				
	Play/Pause / TS		Pause				
	Stop		Stop				
	Rec		Rec				
	Text		Text				
	<< / PVR List		<<				
	<< / PVR List		List				
	>> / DTV/Radio		>>				
	>> / DTV/Radio		TV/R				
	I<< / Fav.CH		I<<				
	I<< / Fav.CH		Pre Ch				
	>>I / Guide		>>I				
	>>I / Guide		Guide				

