






































































Originale	Sostituto
 Power	 Power
 Audio I/II	 Dual
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Sleep	 Sleep
 Recall	 Back
 Exit	 Exit
 Menu	 Menu

Originale	Sostituto
 Source	 AV
 Info	 Info
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Vol +	 Vol +
 Vol -	 Vol -
 CH +	 Ch +
 CH -	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 P.Mode	 Format
 S.Mode	 Shift + Dual





	Originale	Sostituto	Originale	Sostituto
	P.Size	Eject		
	Subtitle	Subt		
	Play/Pause / TS	Play		
	Play/Pause / TS	Pause		
	Stop	Stop		
	Rec	Rec		
	Text	Text		
	<< / PVR List	<<		
	<< / PVR List	List		
	>> / DTV/Radio	>>		
	>> / DTV/Radio	TV/R		
	I<< / Fav.CH	I<<		
	I<< / Fav.CH	Pre Ch		
	>>I / Guide	>>I		
	>>I / Guide	Guide		

